



**Montageanleitung Winddrucksicherung
für die e² Serie 9/WDSE
assembly instructions wind pressure protection
for the series e² 9/WDSE
Best.-Nr. / Order No. 39860**

Sicherheitshinweis

DE



Vorsicht! Jede Montagearbeit am Lüftungsgerät darf nur bei abgetrennter Netzspannung erfolgen!

Hinweise

DE


Minimal benötigte Rohrlänge:

- e² / e²60: 370 mm
- e²short / e²60short: 290 mm


Montage

DE

Montagesteg der Winddrucksicherung in die Aussparungen* im Gehäuse des Lüftereinsatzes einpressen.



Lüftereinsatz in das Montagerohr einschieben, Montagesteg der Winddrucksicherung dabei senkrecht positionieren, Spannungsversorgung anschließen, Innenblende mit Filterrahmen aufsetzen.



Safety instructions

EN



Caution! Any assembly work on the ventilation unit may only be carried out when the mains voltage is disconnected!

Note

EN


Minimum pipe length required:

- e² / e²60: 370 mm
- e²short / e²60short: 290 mm


Installation

EN

Press the installation bar of the wind pressure protection into the recesses* in the housing of the fan insert.



Slide the fan insert into the mounting tube, positioning the mounting bar of the wind pressure protection vertically, connect the power supply, put on the inner cover with the filter frame.



LUNOS Deutschland
LUNOS Lüftungstechnik GmbH & Co. KG
für Raumluftsysteme
Wilhelmstr. 31
13593 Berlin · Deutschland

Tel. +49 30 362 001-0
Fax +49 30 362 001-89
info@lunos.de
www.lunos.de

E130 12.22